

Woven Materials


Does Woven Fiber Color Vary?

Most manufacturers use strict quality control standards to help ensure consistent color of our all-weather wicker fiber. Colors and color-blends may vary slightly from unit-to-unit due to subtle difference in dye lots, the use of variegate fibers and the hand-woven nature of the furniture.

Our all-weather wicker fiber is environmentally friendly and highly resistant to fading, cracking or tearing even after years of use. Fibers have variegated tones, textures and/or matte finishes for an incredibly natural, authentic appearance.

Cleaning Woven Materials

To clean your woven furniture, rinse the frame with fresh water using a high hose pressure. Be careful to avoid any teak details on the furniture as the high pressure can erode the surface of the timber. Optionally, you may wash the woven material with mild detergent and warm water using a soft brush.



Woven Materials continued

After washing, rinse with fresh water until there are no soap bubbles remaining. Allow the furniture to air-dry. If using a specialty outdoor furniture cleaner, avoid using a foaming product, as foam cleaners can leave residue in the gaps of the weaving and later attract dirt.

Winter Storage

Gasper recommends that woven furniture be stored for the winter in climates exposed to snow and freezing temperatures. Furniture must be stored in an upright position to allow for proper water drainage. Storing furniture upside-down may cause water to accumulate and freeze inside the frame, causing structural damage. Always thoroughly clean your furniture before placing in storage. The best place to store your furniture is a dry garage, garden shed or basement. You may also store your woven furniture outdoors using furniture covers.

